


WZ<sup>3</sup>16:2



Aux1 Out-> Monitors EQ

'A' Out -> Teac CD-RW

Left Out -> Mains EQ

Mono Out: Broken