

Wiring

Mac inputs:

Audio in: PA to Mac

A&H mixer Aux4(TRS) → (XLR)Maya22(USB) → J5 Hub → Either Mac USB port.

Video in: Camera to Mac

Canon Eos Camera USB port → (USB)J5 Hub(USB) → Either Mac USB port.

Mac outputs:

Audio out: Mac to PA

Either Mac USB port → J5 Hub → (USB)Maya22(left & right TRS) balanced audio cables
→ TRS Y-adapter → A&H mixer Ch14 line input (marked 'Mac').

Audio out: Mac to Broadcast (Zoom, Youtube, Facebook):

All within the Mac – see 'CSL_SC_Broadcast_Mac_Checklist.pdf' PA mixer does not effect.

Video out: Mac to desk monitor

Either Mac USB port → VGA adapter → monitor at desk

Video out: Mac to stage displays

Either Mac USB port → J5 Hub → Long HDMI cable → HDMI hub → HDMI cables to displays

Video out: Mac to Broadcast (Zoom, Youtube, Facebook):

All within the Mac – see 'CSL_SC_Broadcast_Mac_Checklist.pdf'

Settings

Canon Eos Camera w telephoto lens, No SD card: <TBD>

ESI Maya22 (USB-Audio interface): see 'CSL_SC_Broadcast_Mac_Checklist.pdf'

MacBook Pro (2017 13-inch Retina): see 'CSL_SC_Broadcast_Mac_Checklist.pdf' ,
'CSL_SC Zoom Checklists.pdf'

Stage video monitors: Video: source set to appropriate HDMI input (same as input cable).

Audio: off.