

## **Avoid loud, possibly speaker-damaging**

### **transient noises:**

#### **CSL\_SC PA Start-up**

Confirm Main faders on mixer are down/off

Turn on mixer etc. at Furman master power switch

Turn on QSC power amp (backstage, stage-right)

#### **CSL\_SC PA Shutdown (reverse order from start-up)**

Set Main faders on mixer to down/off

Turn off QSC power amp

Turn off mixer etc. at Furman master power switch

Please don't modify the amp's rotary-control settings: they're set to get the best signal/noise ratio at the mixer and the recording from the mixer.