

Wiring

Mac inputs:

Audio in: PA to Mac

A&H mixer Aux4(TS) → (TS)Maya22(USB) → J5 Hub → Either Mac USB-C port.

Video in: Cameras to Mac

Canon Eos cameras' USB port → (USB)J5 Hub(USB) → Either Mac USB-C port.

Mac outputs:

Audio out: Mac to PA

Either Mac USB-C port → J5 Hub → (USB)Maya22(left & right TRS) balanced audio cables
→ TRS Y-adapter → A&H mixer Ch14 line input (marked 'Mac').

Audio out: Mac to Broadcast (Zoom, Youtube, Facebook):

All within the Mac – see 'CSL_SC_Broadcast_Mac_Checklist.pdf' PA mixer does not effect.

Video out: Mac to desk monitor

Either Mac USB-C port → VGA adapter → monitor at desk

Video out: Mac to stage display(s)

Either Mac USB-C port → J5 Hub → Long HDMI cable → HDMI hub → HDMI cable(s)
to display(s)

Video out: Mac to Broadcast (Zoom, Youtube, Facebook):

All within the Mac – see 'CSL_SC_Broadcast_Mac_Checklist.pdf'

Settings

Canon Eos Cameras, No SD card: <TBD>

ESI Maya22 (USB-Audio interface): see 'CSL_SC_Broadcast_Mac_Checklist.pdf'

MacBook Pro (2017 13-inch Retina): see 'CSL_SC_Broadcast_Mac_Checklist.pdf'

Stage video monitors: Video: source set to appropriate HDMI input (same as input cable).

Audio: off.