Avoid loud, possibly speaker-damaging transient noises:

CSL SC PA Start-up

Confirm Main faders on mixer are down/off

Turn on mixer etc. at Furman master power switch

Turn on subwoofer (stage-right)

Turn on QSC power amp (backstage, stage-right)

CSL_SC PA Shutdown (reverse order from startup)

Set Main faders on mixer to down/off

Turn off QSC power amp

Turn off subwoofer (stage-right)

Turn off mixer etc. at Furman master power switch

Please don't modify the amp's rotary-control settings: they're set to get the best signal/noise ratio at the mixer and the recording from the mixer.