

PLEASE USE SWITCH ON FURMAN TO POWER EVERYTHING ON/OFF

Use a microphone

Mic into → Mixer channel 1 → Mixer 'Main' L&R →
through Kush Electra Stereo Equalizer →
to Mackie SRM450 Powered Speakers (Volume: Unity)

Play audio/music from your phone or computer:

Stereo mini audio cable hanging off left side of rack →
into Mixer channels 5 & 6 → Mixer 'Main' L&R →
through Kush Electra Stereo Equalizer →
to Mackie SRM450 Powered Speakers (Volume: Unity)

Play CD/DVD/Blu-ray video & audio on the TV: CONFIRM

Sony UPB-X800 Multi-disk player →
through HDMI switch (Input 1) →
Samsung 60" TV (HDMI-In-2) Change TV audio volume w remote

Play computer video (& audio) on the TV:

HDMI cable hanging off left side of rack →
Samsung 60" TV (HDMI-In-1)

Play audio from TV thru speakers: (ǃMute TV volume w remote if desired OK??)

Digital Audio from TV →
through Schiit Gungnir DAC (Toslink) →
through Mixer channels 7 & 8 → Mixer 'Main' L&R →
through Kush Electra Stereo Equalizer →
Mackie SRM450 Powered Speakers (Volume: Unity)

Gear & Manuals:

Furman PL-Plus-C **Power** Conditioner: https://cdn.shopify.com/s/files/1/0884/1006/3168/files/pdf_PL-PLUSC_manual.pdf

Kush Electra Stereo **Equalizer** : <https://objects-us-east-1.dream.io/kushfiles/manuals/OP%20OVERVIEW%20-%20Electra%2019.pdf>

Mackie ProFX10v3 **Mixer**: https://mackie.com/img/file_resources/ProFXv3_Series_OM2024July.pdf

Mackie SRM450 Powered **Speakers**: <https://loudaudio.netx.net/api/file/asset/10589>

Schiit Gungnir Digital-to-Analog Converter (**DAC**): <https://www.manualshelf.com/manual/schiit/gungnir/owner-s-manual-english.html>

Samsung UN60KU630DF 60" 4K UHD **TV**: https://downloadcenter.samsung.com/content/UM/201612/20161209095658187/ENG_US-JZATSCK-1.2.2.pdf

Sony UPB-X800 Multi-**Disc Player**: <https://www.sony.com/electronics/support/res/manuals/4687/46873091M.pdf>

Repaired issues

No sound out from Mackie speakers.

Intermittent power-cord connection on Kush EQ.

Replaced power cord Aug 16 '25